

**CET360 MICROPROCESSOR ENGINEERING**  
**μTerm LCDC Implementation Guide**  
**by J. Sumey**  
**ver. 2.6 / 20-Mar-2009**

Abstract

This guide presents the requirements and implementation strategy for adding a multiline LCD display to the CET360 term project. Although the contents of this guide should be familiar to all project team members, the primary audience is the hardware and software specialists. The result of successful application of this guide will be a text-only LCD “driver” module in the form of LCD.h *interface* and LCD.c *implementation* files.

**Table of Contents**

1.	Introduction .....	2
2.	Technical References .....	3
3.	Hardware / Interfacing .....	3
4.	Software / Programming .....	3
4.1	MCU Interface Select and Operation .....	5
4.2	LCDC Instruction Set .....	6
4.3	Memory Mapping and Cursor Addressing .....	7
4.4	LCDC Initialization .....	7
4.5	Other LCD Driver Routines .....	8
4.6	Scrolling .....	9
4.7	Convenience Macros .....	11
5.	Q&A .....	11
6.	References .....	11

## 1. Introduction

As described previously, our microterm project will use an LCD Controller (LCDC) as shown in figure 1. The particular LCDC IC we are using is the RAiO RA8835 as implemented by Topway on their TCB1335 controller board. The RA8835 is the modern version of the 1330/1335 series of LCDC ICs made by Epson/Seiko, S-MOS, etc. that were popular in the 1990s.




Fig. 1: Topway TCB1335 LCD Controller Board

The RA8835 is a programmable controller IC with the following features:

- can accommodate monochrome LCD panels with resolutions up to 640x256 pixels
- supports text, graphics, and combined modes
- built-in character generator ROM and support for user-defined character generation (both RAM- and ROM-based)
- programmable cursor control
- industry-standard 8-bit microprocessor interfaces (Intel 8080 and Motorola 6800 modes)
- 60-pin quad flat package (QFP)
- 2.7V to 5.5V operating supply

Features of the Topway TCB1335 controller board include:

- on-board LCDC IC oscillator (X1)
- on-board 32 KB SRAM display memory (U1)
- 5.0±0.5V operation, 13mA typ.
- on-board DC-DC converter to generate  $V_{EE}$  (-20V) required for LCD panel
- 20-pin MCU interface (K2)
- 16-pin LCD panel interface (K3)

We will also be using the LM2028 LCD panel as the display with the following features:

- 320hx240v pixels
- 3~5.5V operation, 3.5mA typ.
- direct interface to K3 on TCB1335
- LED backlight built-in (3.5V @ 300mA)

## 2. Technical References

There are two primary references you will need when working with the LCDC – one for the TCB1335 controller board<sup>1</sup> (for hardware interfacing) and one for the RA8835 controller IC<sup>2</sup> (for software programming). Check the resources page on the course website for links to these two documents. You may also need to refer to the datasheet for the particular LCD panel you will be using.

## 3. Hardware / Interfacing

The TCB1335 is interfaced to a control processor (our ‘S12) via 20-pin connector K2 using an 8-bit data bus and a single address line (A0). Control lines include an active-low *chip select* ( $\overline{CS}$ ) and either active-low *read* ( $\overline{RD}$ ) and *write* ( $\overline{WR}$ ) lines in 8080 mode or  $R/\overline{W}$  and *Enable* (E) lines in 6800 mode. The *reset* ( $\overline{RES}$ ) line needs to connect to the system reset line. The choice of interface mode is made via the *interface select* pin (SEL1) also on K2. Because the bus interface mode would not need to be changed once selected, this pin should be permanently tied to either  $V_{DD}$  or  $V_{SS}$  for a fixed logic high or low respectively. Refer to section 4.1 below about how to best handle the SEL1 pin. In addition to supplying the board with usual power connections ( $V_{DD}$  and  $V_{SS}$ ), you will also need an external contrast control potentiometer on your breadboard as shown in figure 2. This potentiometer allows you to adjust the contrast of the LCD panel by varying the bias voltage ( $V_O$ ) between  $V_{DD}$  and  $V_{EE}$ . Finally, the TCB1335 also supports backlight power connections for backlit panels by passing through the BLA (anode) and BLK (*kathode*) pins from K2 to K3 (LCD panel connection). For the LM2028 panel operating on 5VDC, a 18~33 $\Omega$  resistor should be used between 5V and BLA. BLK must connect to ground.




Fig. 2: LCD Contrast Control

Recall that the particular S12C32 MCU we are using on the Dragonfly does not implement an external data/address bus architecture; thus you may think that it is not possible to interface a peripheral type device such as this LCDC IC to an MCU that is missing conventional bus pins. Indeed, our S12C32 MCU can be described as being *peripheral bus challenged*. But wait: this is Microprocessor Engineering – all things are possible! You will need to work with your team to devise a scheme wherein you can “emulate” traditional bus operation using the I/O pins available on our C32. *Hint*: use port T as a bidirectional “data bus” and some port M pins for “control bus” signals as mentioned above plus the A0 address line.

**CAUTION!** Use extreme care when wiring the 20-pin DIP ribbon connector to the TCB1335 – this connector does not use standard pin layout numbering!

## 4. Software / Programming

From a software implementation point-of-view, the LCDC/LCD combination should be viewed as an output peripheral (albeit a sophisticated one). In a fashion similar to the SCI module

previously encountered, you should think in terms of a software “module” consisting of the prescribed “.c” driver file (the implementation) and a “.h” header file (the client interface). From a *client’s* (i.e. the main program) perspective, the following actions would be desirable:

- initialize the LCDC
- clear the LCD screen and move the cursor to the upper left corner
- position the cursor to a particular line and column
- output a single character at the current cursor position
- output a character string at the current cursor position
- scroll the screen contents up one line (“pan down”)
- scroll the screen contents down one line (“pan up”)

Also, the client may want to know the screen geometry in terms of the number of lines and characters per line displayable on the actual LCD. The screen geometry can vary from one LCD model to another and may also depend on the character matrix geometry. For example, the LM2028 QVGA LCD panels display a fixed 320h x 240v pixels. Given a 6x10 pixel character matrix layout, this panel would then display 24 character lines of 53 characters per line. The lines would be numbered 0..23 and the character columns would be numbered 0..52. The 5x7 character bitmaps provided by the character generator ROM built into the LCDC would fit nicely into a 6x10 character matrix with 1 blank pixel column between characters horizontally and 3 blank pixel lines between character lines.

Did you notice the top-down approach being taken here? It all starts with “*what would the client of your LCD module need to know and do?*”. Based upon the above description, we have our basic header file designed as shown in figure 3! Obviously, this header file would be *#included* by any client wishing to interact with the LCD (i.e. **main.c**).

```

/*
 * LCD.h: interface for LCD driver
 */

#define LCD_LINES 24           // number of character lines
#define LCD_COLS 53           // number of columns per line

void LCD_init(void);           // initialize LCD controller
void LCD_clear(void);          // blank out entire LCD
void LCD_goto(int line, int col); // move cursor to given line/col
void LCD_putc(char);           // output a single char to LCD
void LCD_puts(char *);         // send char string to LCD
void LCD_scrollUp(void);       // scroll screen contents up
void LCD_scrollDn(void);       // scroll screen contents down

```

Fig. 3: Basic LCD Driver Header File

Moving on to the actual driver itself (LCD.c), this is where we find all the detailed programmatic coding to implement the above functions as well as any additional “support” routines internal to the LCD driver. The support routines would typically be the very low-level functions that interact with the LCDC itself. Of course, these would be considered private to the LCD implementation and not be made available to the client via the header file. In order to design and implement the software driver for the LCD, you will need to frequently refer to the LCD controller IC data sheet. This reference should be thoroughly reviewed prior to continuing with these notes, which are based on this assumption. Required technical knowledge of the LCDC is highlighted in the following sections.

#### 4.1 MCU Interface Select and Operation

From section 5 of the RA8835 data sheet, “Pin Descriptions”, you will note that the SEL1 pin selects between Intel/8080 and Motorola/6800 modes. Although either mode works equally well, the 8080 mode with separate  $\overline{RD}$  and  $\overline{WR}$  lines features slightly simpler strobe timing and is therefore recommended. For MCU writes, the A0 address line selects between a “data” register (when low) and a “command” register (when high). Figure 7-2A in the RA8835 data sheet shows a typical 8080-mode interface and timing details are given in figure 10-3-1 of the data sheet. This information is extremely important to both the hardware and software specialists and should be thoroughly reviewed. As mentioned previously, we will be “emulating” bus-style command and data transfers with the LCDC with our “busless” S12 MCU module. Looking at the data sheet timing diagram of figure 10-3-1, we see the “recipe” for a MCU write operation:

1. set the A0 line high (for command register) or low (for data register)
2. drive CS active-low
3. output a byte to the data “bus” and make sure the I/O port is an output
4. pulse the WRite line active-low then back to high
5. return the CS back to high

Given appropriate definitions for LCDBUS, LCDDDR, A0, CS, WR, HIGH, and LOW, we can implement a “wrLCD” routine as given in figure 4 that will output a specified data byte to the appropriate register in the LCDC. *Observation:* Did you notice how we jumped from a top-down to a bottom-up approach here? Sometimes in embedded systems development, it may make sense to apply step-wise development bouncing between top-down and bottom-up processes to effectively meet in the middle.

```

/*
 * wrLCD: lowest-level routine to write given data byte to LCDC
 *   in: reg = address to write (1=command, 0=data),
 *       data = data byte to write
 *   out: none
 */
void wrLCD(int reg, Byte data)
{
    A0 = reg;           // drive A0 line as given
    CS = LOW;           // assert Chip Select
    LCDBUS = data;      // send datum to LCDC
    LCDDDR = 0xFF;      // make sure I/O port is all outputs
    WR = LOW;           // stobe command byte to LCDC
    WR = HIGH;
    CS = HIGH;          // deassert Chip Select
}

```

Fig. 4: Low-level “wrLCD” Routine

It is also possible to perform read operations from the LCDC. This would occur if you wanted to obtain either the LCDC’s current cursor position or display memory contents. In such cases, a low-level “rdLCD” routine as given in figure 5 would be required.

```

/*
 * rdLCD: lowest-level routine to read & return a data byte from LCDC
 *   in: address to read (1=command, 0=data)
 *   out: byte value read
 */
Byte rdLCD(int reg)
{
    Byte result;
    LCDDDR = 0;           // set I/O port to all inputs
    A0 = reg;             // drive A0 line as given
    CS = LOW;             // assert Chip Select
    RD = LOW;             // assert RD strobe (8080 mode)
    asm nop;              // read setup delay
    result = LCDBUS;      // read datum from LCDC
    RD = HIGH;            // deassert RD strobe
    CS = HIGH;            // deassert Chip Select
    return result;        // return datum read as result
}

```

Fig. 5: Low-level “rdLCD” Routine

## 4.2 LCDC Instruction Set

Because the LCDC is a fairly complex logic device, it implements a number of instructions that may be followed by a variable number of data bytes according to the function of the instruction. Section 6 of the RA8835 data sheet, “Instruction Set”, includes the instruction set summary table followed by detailed descriptions of each instruction. Data sheet section 8-1-2 gives an initialization example which serves as the recipe for setting up the LCDC, for which `LCD_init()` has been identified to accomplish. You will need to study these sections thoroughly to understand how these instructions are used. We will explore `LCD_init()` in more detail in a later section.

For ease of programming within your LCD module (and to eliminate *magic numbers*!), a block of `#defines` should be placed near the top of your `LCD.c` to define appropriate symbolic names for the various LCDC commands. Note that these defines belong in `LCD.c` instead of `LCD.h` because they are used exclusively in the driver implementation and never directly by the client! These names also serve to provide a degree of documentation and increase overall code quality. Figure 6 should give you the idea.

```

/*
 * LCD Instruction Set (from RA8835 data sheet)
 */
#define CMD_SYSTEMSET  0x40      // Initialize device and display
#define CMD_SLEEPIN    0x53      // Enter standby mode
#define CMD_DISPLAYOFF 0x58      // Turn display off
#define CMD_DISPLAYON  0x59      // Turn display on
    : // etc. (13 more lines)

```

Fig. 6: LCDC Instruction Set Symbolic Definitions

As a quick introduction, the commands in the *system control* and *display control* classes are typically used only once during initialization while those in the *drawing control* and *memory control* classes are used for general display content updates.

### 4.3 Memory Mapping and Cursor Addressing

As documented in the data sheet, the LCDC also provides a 16-bit address / 8-bit data interface to its own *display memory* and the TCB1335 board includes 32KB of high-speed static RAM at 0x0000-0x7FFF for this display memory. The idea here is that your driver has to store ASCII codes in the display memory which results in the respective character appearing on the LCD screen. There are essentially two tricks to making this work correctly:

- 1) The display RAM is on the “other side” of the LCDC; thus the “MWRITE” LCDC instruction must be used to get the ASCII codes transferred through the LCDC and into the display RAM, and
- 2) The actual screen contents are mapped to a range of addresses in the display RAM; thus ASCII codes must be written to specific display RAM locations to have them appear at particular locations on the screen. See section 7-10 of the RA8835 data sheet for further details.

The second requirement is exactly the reason for the “CSRW” (Cursor Write) instruction – so that you can move the LCDC’s cursor around the display RAM thus causing subsequently written characters to appear at controlled locations on the screen. The LCDC is also capable of generating pixel-based graphics; however, this feature is not covered in this document. For simplification, we will initialize the LCDC for no graphics page and a single character display page starting at display memory location zero. A 24 line x 53 column text display would therefore require a total of 1,272 bytes of display RAM for a full screen display. Note that this small amount of display RAM (approx. 1.25KB) is typical of textual displays. However, a single 640x240 monochrome graphics page would require 20KB of the display RAM.

Challenge question: how much RAM would be required for a 1024x1024 color graphics display using 24-bits per pixel?

### 4.4 LCDC Initialization

In order to initialize the LCDC and therefore the LCD screen display, you will need to determine the appropriate data byte values for all the commands from “SYSTEM SET” through “OVLAY” and arrange for `LCD_init()` to produce a series of write operations to accomplish the initialization. Although you could use the `wrLCD()` low-level routine in figure 4 to send out each command and data byte individually (30+ writes), this would be extremely tedious, error-prone, and difficult to maintain. A much better method to accomplish this would be to combine a set of initialization parameter *arrays* with a new “wrCommand” routine built on top of `wrLCD()` to off-load the grunt work from `LCD_init()`. For example, the following line of code would encapsulate the 8 data bytes required for the “SYSTEM SET” command into a data array. Note that these values are specifically chosen for the LM2028 LCD geometry, a different LCD geometry would require different values.

```
const Byte ParamsSysSet[] = {0x10, 0x05, 0x09, 52, 55, 239, 53, 0};
```

This definition, along with five others for those initialization commands requiring data parameters, would be placed at the top of `LCD.c` after all `#defines` but before any routines. Once the initialization data arrays are built, we next add `wrCommand()` as shown in figure 7. This nifty utility routine accepts three arguments: a command, a pointer to a parameter data array (which may be null), and the array length (which may be 0) and takes care of writing out a complete command plus parameters to the LCDC using the lowest-level `wrLCD()` routine previously described.

```

/*
 * wrCommand: low-level routine to write command & data to LCDC
 *   in:  command = LCD command,
 *        *parms = array of byte parameters,
 *        length = length of parameter array (0 if none)
 *   out: none
 */
void wrCommand(Byte command, const Byte *parms, Byte length)
{
    int i;
    wrLCD(1, command);           // output the LCDC command
    for (i=0; i<length; i++)     // output all parameter bytes
        wrLCD(0, parms[i]);
}

```

Fig. 7: "wrCommand" Routine

Now that we have a series of parameter data arrays and the `wrCommand()` routine, the `LCD_init()` routine becomes drastically simpler as shown in figure 8.

```

/*
 * LCD_init: initialize LCDC
 */
void LCD_init(void)
{
    // initialize LCD output control lines
    :
    // initialize data direction registers
    :
    // LCDC initialization sequence according to data sheet fig. 8-1
    wrCommand(CMD_SYSTEMSET, ParamsSysSet, sizeof(ParamsSysSet));
    wrCommand(CMD_SCROLL, ParamsScroll, sizeof(ParamsScroll));
    :
    // 5 more calls to wrCommand() here
    LCD_clear(); // erase all the garbage from power-up
}

```

Fig. 8: "LCD\_init" Routine

## 4.5 Other LCD Driver Routines

The initialization process is probably the most difficult part of the LCD driver. A test run at this point should produce a blank display with a blinking underline cursor in the top-left corner. Don't forget to adjust the contrast control if need be! Once you have that working, the remaining routines should be a breeze. The following sections provide some hints on what the other LCD driver routines should do.

### 4.5.1 LCD\_clear()

- position the cursor to 0,0 [call `LCD_goto(0,0)`]
- use a *for* loop to output "LCD\_LINES \* LCD\_COLS" ASCII blank spaces via `LCD_putc()`
- reposition the cursor to 0,0

### 4.5.2 LCD\_goto(int line, int col)

- compute a new display memory cursor address based on the given line & col
- use `wrCommand()` with `CMD_CSRW` to update the LCDC's cursor address



*Hint: be careful of the byte ordering here – since the S12 is “big endian”, you’ll need to swap bytes before sending to the LCDC.*

#### 4.5.3 LCD\_putc(char chr)

- If the given char is not a control character, use `wrCommand()` with `CMD_MWRITE` to output the ASCII character and exit `LCD_putc()`. In order to send ‘chr’ to `wrCommand()`, you’ll need to pass chr’s address using the ‘&’ C operator (you may also need a typecast here).
- for the control characters listed in figure 9, handle appropriately

Ctrl Char	Function
BS	move cursor left one column unless already in col 0
HT	move cursor right to next “tab stop” (even multiple of 8 columns)
LF <sup>†</sup>	move cursor down 1 line, calling <code>LCD_scrollUp()</code> if needed
VT <sup>†</sup>	move cursor up 1 line, calling <code>LCD_scrollDn()</code> if needed
FF	clear screen and home cursor; i.e. call <code>LCD_clear()</code>
CR	move cursor to column 0 of current line

Fig. 9: Basic Control Character Functions

<sup>†</sup>: VT and LF should be able to scroll past the top and bottom lines respectively.

#### 4.5.4 LCD\_puts(char \*str)

- Call `LCD_putc()` in a loop for each character in the given string, just like you did in `SCI_puts()`.

#### 4.5.5 LCD\_scrollUp()

- forward scroll display screen contents by 1 line  
*Hint: advance the LCDC’s startaddress (SAD1) of your text page by `LCD_COLS` bytes. Don’t forget to also clear the newly exposed line at the bottom of the screen. See the RA8835 data sheet, section 7-13 for additional details.*

#### 4.5.6 LCD\_scrollDn()

- backward scroll display screen contents by 1 line  
*Hint: see the hint for `LCD_scrollUp()`!*

### 4.6 Scrolling

What should happen when the LCD screen is filled, the cursor is at the bottom-right corner, and one more character is sent to the LCD module? A first possibility would be to start over in the top-left corner, effectively overwriting the current display. This is not considered “standard” behavior. The second and generally accepted possibility is to shift the bottom n-1 lines to the top n-1 lines and continue displaying additional characters on the new bottom line. However, as you might guess, it would be an ugly and time-consuming process to move all these characters and lines programmatically.

As described in section 7-13 of the RA8835 data sheet, “Scrolling”, and shown there in figure 7-24, we can employ the LCDC’s inter-page scrolling feature to support very high-speed,

hardware-assisted display scrolling. Although the displayed screen contents will initially be generated from the first “page” of display memory, the 32KB of display RAM on the TCB1335 board can support a large number of display pages. The trick to getting display scrolling to work is to manipulate the LCDC’s *startaddress1* (SAD1) register via the SCROLL command. For the `LCD_scrollUp()` function, you would add `LCD_COLS` to SAD1. This effectively moves line 2 to line 1, line 3 to 2, etc. and would open a new line at the bottom of the display; which you should clear to all blanks. This addition process could continue as needed and the 16-bit address counter registers within the LCDC would simply wrap-around at the end of the display memory.

For reverse-scrolling, `LCD_scrollDn()` would subtract `LCD_COLS` from SAD1. No clearing of the newly recalled line 1 would be needed resulting in the feature to scroll back in display history.

When scrolling the display contents, there are two other small problems that must be properly handled. The first problem is when doing cursor addressing in `LCD_goto()`, the changing display start address must be added to the new cursor address to insure the new cursor location appears in the proper location on the screen. The easiest way to solve this problem is have a word variable local to `LCD.c` that keeps track of the current value of SAD1. Thus, `LCD_scrollUp()` and `LCD_scrollDn()` should respectively add and subtract `LCD_COLS` to this variable and rewrite this variable to SAD1 via the SCROLL command. Then in `LCD_goto()`, you would also add this variable to the new cursor address before sending this value to the CSRW command.

The second problem is the position of cursor when performing scrolls. If the cursor position is not adjusted during the scroll operation, it will move away from its current position (and possibly even off-screen!) which is quite distracting to the user. Indeed, the cursor should also move down or up by one line for each `LCD_scrollUp()` or `LCD_scrollDn()` call respectively. The solution for this would be for both of these routines to first acquire the current cursor position relative to the beginning of the display, then to update SAD1 as described in the previous paragraph, and then finally to reposition the cursor to the previous relative position. To acquire the current relative cursor position, these two routines could call a new low-level support routine, `getCrsAddr()` shown in figure 10, to retrieve the LCDC’s cursor address register via the CSRR command and then subtract the current display start address. This value would then be used by `LCD_scrollUp()` and `LCD_scrollDn()` before exiting by calling `LCD_goto()`.

```

/*
 *  getCrsAddr: get & return current cursor address
 *      in: none
 *      out: current cursor address as a 16-bit int
 */
Word getCrsAddr()
{
    Byte parms[2];
    wrCommand(CMD_CSRR, NULL, 0); // issue cursor read command
    parms[0] = rdLCD(1);
    parms[1] = rdLCD(1);
    return (parms[1]*256 + parms[0]); // byte swapped
}

```

Fig. 10: Low-level “getCrsAddr” Routine

## 4.7 Convenience Macros

One of the neatest tricks of programming in C is the use of the preprocessor's macro feature. In the development of embedded system projects, the macros shown in figure 11 demonstrate some commonly needed constants and functions. The MSB, LSB, and SWAP macros manipulate a word argument while the PULSE macros may be used to create logic pulses on output pins.

```
// some handy macros
#define LOW 0
#define HIGH 1

// extract most significant byte of a word
#define MSB(w) (w >> 8)
// extract least significant byte of a word
#define LSB(w) (w & 0xff)
// swap high/low bytes of a word
#define SWAP(w) (MSB(w) + (LSB(w)<<8))

#define PULSE_LO(pin) pin=0; pin=1 // create active low pulse
#define PULSE_HI(pin) pin=1; pin=0 // create active hi pulse
```

Fig. 11: Some Handy Macros

## 5. Q&A

*[possible question / answer section here – what would you like to see here?]*

## 6. References

1. *TCB1335 LCD Module Controller Board User Manual*, rev. 0.1, Topway Technology Co., Jun. 2004.
2. *RA8835 Dot Matrix LCD Controller Specification*, ver. 1.7, RAiO Technology Inc., Aug. 2006.